

## Nokia 7600 Information

### Useful Links:

- Updated PC Suite Software from Nokia (Provided CD contains version 6.1, website is 6.6):
  - <http://www.nokia.com/nokia/0,,72014,00.html>

### Changing Between 2g/3g Networks

1. Insert the sim card of your choice into the phone as described on Page 18 of the Nokia Manual. You may now charge the battery and continue with these steps at the same time.
2. Turn on the phone, and access the **Menu -> Settings -> Phone Settings -> Network Mode**
3. Then to work in 2g only mode select **GSM**
4. To turn the phone back to work on 3 or other 3g networks simply choose **Dual mode** from that menu.
5. The phone should now work fine with your normal 2g sim card from any network.

More instructions on this see page 65-66 of the Nokia manual.

### Network Settings

You can visit the Nokia website @

<http://www.nokia.co.uk/nokia/0,,54551,00.html> which will allow you to get your network settings sent to your nokia phone free of charge. You will need both the "**Get MMS Settings**" and "**Get WAP/GPRS Settings**". Once you have received the settings, **your phone must be set to these settings**, follow the steps below to do this. They do not send 3 network settings as yet. If you need them, email me @ [blueghostuk@gmail.com](mailto:blueghostuk@gmail.com)

### Changing Network Settings

1. Select Menu -> Message Settings -> Multimedia msgs.-> Connection Settings -> Select the relevant network – **this should mention MMS or picture settings**. Select Menu -> Media Player -> Streaming sett. -> Active connection settings -> Select the relevant network – **this will mention GPRS or WAP. Don't use anything that mentions picture messaging**.
2. Select Menu -> Connectivity -> GPRS -> GPRS Modem Settings -> Active Access Point -> Select the relevant network, again ignore the Picture Message option

3. Select Menu -> Services -> Settings -> Connection Settings -> Active service settings -> Select the relevant network, again ignore the Picture Message option

I hope this helps, if you have any problems then email me at the address in the header of this page. If you add any more network settings from the Nokia website then obviously more options will become available when selecting the settings above. Anything that mentions MMS/Picture Messaging is only for step 1 above.

### Links to other sites

- <http://www.unlockme.co.uk/> - Free Unlocking Software and Guides
- [http://www.trycktill.com/eng/unlock\\_swe.asp](http://www.trycktill.com/eng/unlock_swe.asp) - Free remote unlocking – see guide on next page
- <http://www.phantomgsm.com/> - Buy cables and other devices from them
- <http://www.mobile-unlocking.org.uk/> - Unlocking Service and others
- <http://www.remoteunlocker.com/shop/> - Unlocking Service and others

## Unlock any Nokia phone to any 2g network

[http://www.trycktill.com/eng/unlock\\_swe.asp](http://www.trycktill.com/eng/unlock_swe.asp) - Use this site, or see my site for other free links – whatever you do don't waste money on eBay auctions offering this service at a cost. It is free!

### Instructions for above Web Site:

Choose your language:   

- First select the English language option towards the bottom left of the page.
- Then choose options *similar* to this for ***your phone and network***: (you have to select one at a time and the page will keep updating)

Brand:	<input type="text" value="Nokia"/>
Model:	<input type="text" value="7600"/>
Country:	<input type="text" value="United Kingdom"/>
Network:	<input type="text" value="23420 ( 3   Hutchison 3G )"/>

- Follow the instructions to get the IMEI Number from the phone, or simply get it off the side of the box.

IMEI:  ← enter code here

Network:

Boxserial:

Send:  Agree by checking the checkbox:

*Read our Disclaimer before you use this service.*

- The Boxserial is usual the default 'Prodigy' one, but look on the outside of your phones packaging to see if there are any numbers such as 32802
- If you see a number like this, choose Manual from the Boxserial dropdown box and enter the code number in the Boxserial field.
- Read the terms and check the box that asks for you to agree to their terms and conditions.
- Once you have clicked the "**Generate Code**" button you will get a list of codes **similar** to the ones seen below, use the ones **they provide** on the site as they are customised to each individual phone.

```
#pw+089063403732475+1#  
#pw+055933476311344+2#  
#pw+954222275204232+3#  
#pw+409217121754121+4#  
#pw+088403402676213+5#  
#pw+396306112425311+6#  
#pw+083823203150431+7#
```

- Follow the instructions below this list on the website titled "**How to enter the generated code**" to finish the process.
- If you have an **Orange** phone then you may need to use code number **5 (ending +5#)**, as codes 1 and 7 may not work although this may not always be the case.

Finally you should be able to use this website to unlock any other compatible phones you have by customising the options above (e.g. virtually any other nokia phone from any UK network etc)

## Full Factory Reset on a Nokia 7600

If you want, or any one you know wants a Nokia 7600 factory reset by me, this would cost from £4.60 including return postage. See [http://www.blueghost.co.uk/unlock\\_guide/7600\\_unlock.html](http://www.blueghost.co.uk/unlock_guide/7600_unlock.html) for more details, or email me.